

# Quick Installation Guide


## KBox E-430-RPL/RPH

Thank you for purchasing the Kontron KBox E-430-RPL/RPH box PC. This document provides information to allow you to quickly install this product.


### ► Packing Checklist

1. Take the KBox E-430-RPL/RPH out of the packing box and check if the unit is properly secure in the plastic bag.
2. Check the contents of the carton box: (\*: optional)
  - 1x KBox E-430-RPL/RPH (corresponding to the ordered system configuration)
  - 1x Power Terminal Block Plug Connector (attached on the system in case of not ordering power adapter)
  - 1x Quick Installation Guide
  - 1x Driver CD
  - 1x Power Adapter\* (power terminal block plug connector attached)
  - Memory Module(s)\* (It may be pre-installed in the system depending on ordered configuration.)
  - Internal 2.5" HDD / SSD\* (It may be pre-installed in the system depending on ordered configuration.)
  - M.2 Key B Expansion Card / SSD\* (It may be pre-installed in the system depending on ordered configuration.)
  - M.2 Key E Expansion Card\* (It may be pre-installed in the system depending on ordered configuration.)
  - M.2 Key M SSD\* (It may be pre-installed in the system depending on ordered configuration.)
  - Antenna(s)\*
  - DIN Rail Mount Kit\*
  - VESA Mount Kit\*
  - Vertical Wall Mount Plate\*
  - Horizontal Wall Mount Kit\*


### ► Front I/O Panel (KBox E-430-RPL Configuration 1)




➤ Front I/O Panel (KBox E-430-RPL Configuration 2)



➤ Front I/O Panel (KBox E-430-RPH Configuration 1)



## ➤ Front I/O Panel (KBox E-430-RPH Configuration 2)



- |   |                                             |    |                            |
|---|---------------------------------------------|----|----------------------------|
| 1 | DC-In 9 V ~ 36 V (+ $\perp$ -, top-down)    | 9  | HDMI 2.0                   |
| 2 | DC-In 11 V ~ 32 V (+ $\perp$ -, left-right) | 10 | USB 3.2 Gen 2              |
| 3 | Power Button                                | 11 | USB 2.0                    |
| 4 | Power LED                                   | 12 | RS232 (Tx / Rx only)       |
| 5 | Standby LED                                 | 13 | 8-bit DIO                  |
| 6 | Storage LED                                 | 14 | Antenna Port               |
| 7 | 2.5 GbE                                     | 15 | Protective Earth Stud Bolt |
| 8 | DisplayPort                                 |    |                            |

### Your Contact

Kontron Asia Inc. / Kontron Asia Technology Inc.

4F, No. 415, Ti-Ding Blvd., Sec. 2,  
Neihu District, Taipei, Taiwan 114741  
Tel.: + 886 2 2799 2789  
SalesAsia@kontron.com

[www.kontron.com](http://www.kontron.com)

**kontron**  
The Power of IoT