## Wich components do you need to control a flat panel with CRTtoLCD-X

1. CRTtoLCD-X controller
2. Power supply with 12V-DC / 3A
3. PC with VGA-signal-output and standard 9-pin RS232 interface
4. Data-Cable for the flat panel (for availability go to the Flatpanel-Configurator on www.kontron-hh.com)
5. *Optional (OSD-Keypad)*
6. *Optional (Serial-Cable to connect the CRTtoLCD-X via RS232)*

All components you need to connect the CRTtoLCD-X are coming with our Starterkit-Accessories (P/N 60901). Visit our homepage www.kontron-hh.com for further details.